



## Product Information

### RINSE AID

**Rinse Aid is a spot-free rinse additive designed to make the final rinse cycle in an automatic dishwasher more effective.**

Rinse Aid is formulated with a mild food acid and foam suppressing surfactants to promote rapid drying and the removal of insoluble calcium salts in the final rinse to leave glassware, cutlery and crockery sparkling and free from water spotting.

This highly concentrated formulation is suitable for use in all automatic dishwashing machines with manual application or automatic pump or venturi systems. Small doses will leave crockery shine and free from water marks.

#### ◆ DIRECTIONS:

Add undiluted Rinse Aid to the machine's dispensing reservoir as per manufacturer's instructions. Adjust dispensing rate to suit the particular water conditions. Refill as required.

#### ◆ BIODEGRADABLE:

The surfactants in this product are biodegradable according to internationally accepted criteria.

#### ◆ PRESENTATION:

Rinse Aid is available in 500ml and 5 litre pack sizes.

#### ◆ HAZARDS:

Harmful if swallowed. Keep out of reach of children.

#### ◆ FIRST AID:

If swallowed: do not induce vomiting. Rinse mouth with water and give water or milk to drink. Seek medical assistance.

For eye or skin contact: flush with water. If irritation develops seek medical attention.

**A Safety Data Sheet is available for this product on request.**