

Cyclone® Shine Up ® Furniture Polish



CYCLONE SHINE UP Furniture Polish is a blend of waxes and silicones to clean and shine most surfaces. CYCLONE SHINE UP Furniture Polish helps repel dust, it reduces dust accumulation and helps protect against ordinary wear, water spills and stains so furniture looks and stays beautiful. CYCLONE SHINE UP Furniture Polish works well on most surfaces, including metal furniture, office equipment, paneling, leather, vinyl, chrome, brass, stainless steel, porcelain, marble, ceramics and laminates.

Use on:



For Best Results:

- Do not allow spray to dry before wiping.
- ▶ For quick touch-ups to small surfaces spray cloth and dust as usual.
- ▶ Surface finishes vary considerably. Try CYCLONE SHINE UP Furniture Polish in a small hidden area to ensure satisfactory results.

Use Overview

Directions for use

- 1. Shake well before each use
- 2. Point nozzle to red dot
- 3. Hold can upright, spray 15cm from surface to be dusted and polished.
- 4. Wipe immediately with a soft, clean cloth.

Product Specifications

Parameter Results Appearance CLEAR LIQUID (AEROSOL DISPENSED) Specific Gravity 0.93

Available Items

Code	Description	Pack Size	Availability
5586071	Cyclone Shine up Furniture Polish	6x500gm	AU & NZ

ADG Information

DG Class	2.1
Shipping Name	AEROSOLS
UN No.	1950
Hazchem Code	2YE

Environmental Update

Recyclable- Container uses 20% recycled steel and when empty, can be fully recycled as recycling collection systems become available.

Safety Reminder:

Please make sure your employees read and understand the product label and Safety Data Sheet before using this product. The label contains directions for use, and both the label and SDS contain hazard warnings, precautionary statements and first aid procedures. SDSs are available online at www.diversey.com or by calling Toll free: Australia, 1800 647 779 or New Zealand, 0800 803 615.



